

HYDRAULIC DUAL BLOCK & STOP VALVES HDBH SERIES

PRODUCT CATALOG





Hydraulic Dual Block & Stop Valve Product Overview

Dual Block & Stop Safety Function

Blocks the flow of hydraulic fluid in order to stop cylinder motion.



Illustration example.

The HDBH Series system is a redundant, dual blocking valve system designed for critical applications where safe stopping is required for hydraulically controlled actuators. This valve system is equipped with inductive position switches for external monitoring by an electrical safety control system. The HDBH valve is designed to be sandwich-style mounted (interposed) between a manifold and a directional valve, or in-line mounted by use of optional mounting kits.

NOTE: Block and Stop functions are intended to momentarily stop an actuator (linear or rotary), but not to hold the actuator in place for an extended period. The HDBH valve is a spool type valve, and normal spool leakage will occur. The valve is intended to be used as a "permissive" safety device. Applications where long-term holding is necessary should also incorporate other components such as PO check, counterbalance, or mechanical locking devices.

NOTE: HDBH valves are intended to be used only for tasks that are routine, repetitive, and integral to production. Maintenance tasks require following full lock-out/tag-out procedures to relieve hazardous energy and prevent unexpected startup.

	VALVE SYS	STEM FEATURES					
External Monitoring		Each single valve in the HDBH Series system is equipped with an inductive position switch. Monitoring of these switches is to be done by an electrical safety control system.					
Spool Type Design	Redundant spool type valve system						
Tamper Resistant	Special tool required for disassembly	у					
Mounting	Mounts between manifold and direct	tional valve					
Flexible Mounting	installation in-line between a directior with multiple ports for the A, B, and must be piped back to the tank. Thro	In applications where installation on a manifold is not practical, the in-line mounting kit can be used to facilitate installation in-line between a directional valve and actuator (typically a cylinder). The kit provides 2 mounting plates with multiple ports for the A, B, and T ports in order to provide for flexibility in piping. At least one of the T ports must be piped back to the tank. Through holes for mounting the assembly are included in the plates. All assembly hardware and plugs are included, but mounting hardware for the assembly must be provided by the customer.					
Flow-doubling	In applications where higher flows are needed, there is an option to combine the flow through both the A & B ports to double the flow capacity of the valve. This doubling effect converts the HDBH valve to a single line blocking valve instead of blocking two lines. The kit provides 2 mounting plates with multiple ports for the inlet and outlet for flexibility in piping and two T(DR) ports. At least one of the T(DR) ports must be piped back to the tank to perform a drain function. All assembly hardware and plugs are included, but mounting hardware for the assembly must be provided by the customer.						
Spacer Kits	Spacer kits are available to raise the HDBH Series system higher above the manifold surface in order to avoid interference with other devices on the manifold. Kits can be combined as necessary to achieve the desired spacing.						
These valves are not designed for controlling clutch/brake mechanisms on mechanical power presses.							
PRODUCT CREDENTIALS							
Performance Level Per ISO 13849-1:2015	Safety Integrity Level Per IEC 2061:2001	DGUV	Declaration of Conformity				
Cat. 4 PL e	SIL 3 Functional Safety	HSM 221189 Sicherheit appriit	C€	UK CA			

Specifications



		S	TANDARD SPECIFIC	CATIONS			
	Function		Dual Block & Stop - blocks both cylinder lines when sandwich mounted or mounted with the In-line Mounting Kit. Blocks only one line when mounted with the Flow-doubling In-line Mounting Kit.				
	Construction Design		Redundant valve system, Spool				
			Solenoid - 2 per systen	1			
	Actuation	Electrical	One solenoid per valve Both to be operated sy				
			Direct solenoid-operate	ed, spring return			
GENERAL			Sandwich-style mount	ing (interposed) betweer	n base/manifold and directional valve		
		Type/ Orientation	In-line mount between	directional valve and ac	tuator (in-line mounting kit required)		
	Mounting	,,,		mount between direction ubling In-Line mounting	nal valve and actuator (In-Line) for single-line kit required)		
		Footprint	ISO 4401-03-02-0-05,	NFPA D03, NG size 6			
	Monitoring				blied equipment. Monitoring should check state Il changes in state of valve control signals. See		
	Minimum Operation Frequency		Once per month, to en	sure proper function			
		Ambient	-22° to 158°F (-30° to	70°C)			
	Temperature	Media	-4° to 140°F (-20° to 6				
			Mineral Oil HLP, HL-DIN 51524				
	Flow Media	Hydraulic Fluids	Vegetable Oil HETG - VDMA 24568				
OPERATING	Flow		5 gpm (10 gpm with Flow-doubling in-line mounting kit)				
CONDITIONS	Max Fluid Contamina	tion Level	ISO 4401 class 21/19/16 NAS 1638 class 10 (filters at 25 µm value with β25 ≥ 75 recommended)				
	Ports P, A, B		5000 psi (350 bar)*				
	Operating Pressure	Port T	3000 psi (210 bar)*				
	operating recours	*Operating Pressure	e for Ports P, A, & B limited to 3000 psi (210 bar) unless T port is used (not blocked)				
			Current Flow	Operating Voltage	Power Consumption (each solenoid)		
	Solenoids		DC	24 volts	30 watts		
			Rated for continuous duty				
ELECTRICAL			Design according to VI	DE 0580			
DATA	Enclosure Rating		DIN EN 60529 IP 65				
	Electrical Connection		DIN EN 175301-803 Form A				
	Inductive Position Switch (2 per system)		PNP (M12, 4-pin, A-coded, male): works with both 4-pin & 5-pin female cord sets				
	Maximum Current (each switch)		400mA maximum				
	Valve Body		Cast Steel				
	Spool		Steel				
CONSTRUCTION	Seals		Buna-N				
MATERIAL	End-brackets		Unfilled Nylon 12				
	Side-brackets (label)		304 Stainless Steel				
-	_	In-line Mounting Kit		Ductile Iron			
	Flow-doubling In-line	: Mounting Kit					


IMPORTANT NOTE: Please read carefully and thoroughly all of the CAUTIONS, WARNINGS on the inside back cover.


Ordering Information

MODEL NUMBER

HDBHDC3BAEXA

Weight lb (kg) 15.0 (6.80)






An Integration Guide for HDBH Series valve system is available from ROSS to provide information such as operation, monitoring, and integration into users control circuits. Please visit www.rosscontrols.com.


System Technical Data



PRESSURE DROP CURVES Port A (valve) to Port A (manifold) & Port B (manifold) to Port B (valve) 1100 1000 **Valve Side** 900 800 **APressure (psi)**200 200 200 (1 A) 400 (1B) 300 200 100 **Manifold Side** 0 12 ---- A (valve side) to A (manifold side) B (manifold side) to B (valve side) Port B (valve) to Port B (manifold) & Port A (manifold) to Port A (valve) 900 800 **Valve Side** 700 600 APressure (psi) 500 (1A) 400 300 200 100 **Manifold Side** 0 12 Flow (gpm) ---- A (manifold side) to A (valve side) B (valve side) to B (manifold side) Port P (manifold) to Port P (valve) & Port T (valve) to Port T (manifold) 70 **Valve Side** 60 APressure (psi) 30 20 **Manifold Side** 12 14 16 Flow (gpm) P (manifold side) to P (valve side) T (valve side) to T (manifold side)


System Technical Data







MOUNTING ACCESSORIES						
	Height	Kit Number	Weight Ib (kg)			
Spacer Kits	0.75 in (19.1 mm)	2548B25	1.0 (0.45)			
	1.75 in (44.5 mm)	2549B25	2.0 (0.90)			
	Kit Type	Kit Number	Weight Ib (kg)			
Mounting Kits	In-line (Blocks 2 lines)	2790B77	47.0 (7.74)			
	In-line Flow-doubling (Blocks 1 line)	2819B77	17.0 (7.71)			



PREWIRED ELECTRICAL CONNECTORS



Illustration example.

Prewired Connector Kits

Cable						
End 1	End 2	Length	0	Quantity	Cord Diameter	Maria A I t- b A
Connector	Cord /Connector	maters (feet) Connection Include		Included	d mm	Without Light
DIN EN 175301-803	Flying leads	5 (16.4)	Solenoid	2	6	2243H77
Form A		10 (32.8)	Solenoid	2	6	2244H77
M12 5-pin, Female	Flying leads M12 5-pin, Male	5 (16.4)	Sensor	2	6	2644B77
		10 (32.8)	Sensor	2	6	2370B77
		5 (16.4)	Sensor	2	6	2645B77
		10 (32.8)	Sensor	2	6	2371B77

Prewired Connectors

		Model Number					
End 1	End 2	Connection Quantity	Length	Cord Diameter	Without Light	Lighted Connector	
Connector	Cord	Connection	Included	meters (feet)	mm	Without Light	24 V DC
DIN EN 175301-803	Flying leads	Solenoid	1	2 (6.5)	6	721K77	720K77-W
Form A	Figility leads	Solellolu	1	2 (0.3)	10	371K77	383K77-W

ELECTRICAL CONNECTORS

			Model Number				
	Туре	Connection	Fitting Connection Quantity Included	ntity Cord Diameter	Without Light Light	Lighted Connector	
	турс	Connection		Included	mm	Without Light	24 V DC
	DIN EN 175301-803 Form A	Solenoid	Cable grip	1	8 to 10	937K87	936K87-W
			1/2" NPT conduit	1	_	723K77	724K77-W

CAUTIONS: Do not use electrical connectors with surge suppressors, as this may increase valve response time when de-actuating the solenoids.

Notes



Notes



ROSS OPERATING VALVE, ROSS CONTROLS®, ROSS DECCO®, and AUTOMATIC VALVE INDUSTRIAL, collectively the "ROSS Group".

CAUTIONS, WARNINGS

Additional technical documentation, cautions and warnings information is available.

STANDARD WARRANTY

All products sold by the ROSS Group are warranted for a one-year period [with the exception of Filters, Regulators and Lubricators ("FRLs") which are warranted for a period of seven (7) years] from the date of purchase. All products are, during their respective warranty periods, warranted to be free of defects in material and workmanship. The ROSS Group's obligation under this warranty is limited to repair, replacement or refund of the purchase price paid for products which the ROSS Group has determined, in its sole discretion, are defective. All warranties become void if a product has been subject to misuse, misapplication, improper maintenance, modification or tampering. Products for which warranty protection is sought must be returned to the ROSS Group freight prepaid.

THE WARRANTY EXPRESSED ABOVE IS IN LIEU OF AND EXCLUSIVE OF ALL OTHER WARRANTIES AND THE ROSS GROUP EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES EITHER EXPRESSED OR IMPLIED WITH RESPECT TO MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. THE ROSS GROUP MAKES NO WARRANTY WITH RESPECT TO ITS PRODUCTS MEETING THE PROVISIONS OF ANY GOVERNMENTAL OCCUPATIONAL SAFETY AND/OR HEALTH LAWS OR REGULATIONS. IN NO EVENT IS THE ROSS GROUP LIABLE TO PURCHASER, USER, THEIR EMPLOYEES OR OTHERS FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES WHICH MAY RESULT FROM A BREACH OF THE WARRANTY DESCRIBED ABOVE OR THE USE OR MISUSE OF THE PRODUCTS. NO STATEMENT OF ANY REPRESENTATIVE OR EMPLOYEE OF THE ROSS GROUP MAY EXTEND THE LIABILITY OF THE ROSS GROUP AS SET FORTH HEREIN.



	,			
Americas	ROSS CONTROLS	USA	Tel: +1-248-764-1800	www.rosscontrols.com
	ROSS CONTROLS CANADA Ltd.	Canada	Tel: +1-416-251-7677	www.rosscanada.com
	ROSS DO BRASIL LTDA	Brazil	Tel: +55-11-4335-2200	www.rosscontrols.com.br
	ROSS EUROPA GmbH	Germany	Tel: +49 (0)6103-7597-100	www.rosseuropa.com
EUROPE	ROSS FRANCE SAS	France	Tel: +33-(0)1-49-45-65-65	www.rossfrance.com
	ROSS PNEUMATROL Ltd.	United Kingdom	Tel: +44 (0)1254 872277	www.rossuk.co.uk
	ROSS CONTROLS INDIA Pvt. Ltd.	India	Tel: +91-44-2624-9040	www.rosscontrolsindia.com
ASIA & PACIFIC	ROSS CONTROLS (CHINA) Ltd.	China	Tel: +86-21-6915-7961	www.rosscontrolschina.com
	ROSS ASIA K.K.	Japan	Tel: +81-42-778-7251	www.rossasia.co.jp
	AUTOMATIC VALVE INDUSTRIAL LLC	USA	Tel: +1-248-474-6700	www.automaticvalve.com
	ROSS DECCO COMPANY	USA	Tel: +1-248-764-1800	www.rossdecco.com
	ROSS PNEUMATROL Ltd.	United Kingdom	Tel: +44 (0)1254 872277	www.pneumatrol.com
	manufactIS GmbH	Germany	Tel: +49 (0)2013-16843-0	www.manufactis.net

Full-Service Global Locations

There are ROSS Distributors Throughout the World

To meet your requirements across the globe, ROSS distributors are located throughout the world. Through ROSS or its distributors, guidance is available for the selection of ROSS products, both for those using fluid power components for the first time and those designing complex systems.

Other literature is available for engineering, maintenance, and service requirements.

If you need products or specifications not shown in this catalog, please visit ROSS' website, contact ROSS or your ROSS distributor. The ROSS Support Team will be happy to assist you in selecting the best product for your application.

1